

PROPER USE OF TOWN OF LEESBURG FIRE HYDRANT METERS

- 1. Use ONLY Leesburg issued fire hydrant meters on Leesburg designated fire hydrants. Failure to comply is a misdemeanor and violation of Leesburg Town Code Section 34-22, punishable by \$2,500 fine, one year in jail, or both. HYDRANT METERS ARE TAGGED IDENTIFYING THEM AS LEESBURG METERS. LEESBURG FIRE HYDRANTS DISPLAY LABELS IDENTIFYING THEM AS LEESBURG HYDRANTS.
- 2. The hydrant meter should only be used at the location specified on the hydrant meter contract.
- 3. The hydrant meter must be stored in an area where it is protected from freezing.
- 4. Only approved wrenches should be used for fire hydrant operation.
- 5. Hydrant should be opened and closed slowly to prevent pressure surges in mains.
- 6. User should run a small amount of water through the hydrant before meter is installed to remove anything that may have accumulated in the hydrant barrel.
- 7. Any leaks or problems noticed in the operation of the fire hydrant or the hydrant meter should be reported to the Department of Utilities at 703-771-2713 or by email at Hydrants@leesburgva.gov immediately.
- 8. The hydrant meter must be installed so that no leaking occurs.
- 9. The fire hydrant should be opened completely; throttling should only be done at the valve on the hydrant meter.
- 10. To remove meter, the hydrant must be fully closed. Remove all hoses, open hydrant meter valve and remove meter using proper wrenches.